

PRODUCT DESCRIPTION

Stonchem 886 is a silica-free and spark-proof, vinyl ester lining system applied at a nominal thickness of 1.5 mm. The resin, engineering fabric, carbon-filled mortarcoat and silica-free topcoat provide a smooth, heavy-duty, and non-sparking chemical barrier which is resistant to small static cracks and moderate thermal shock. The Stonchem 886 system has excellent resistance to hydrofluoric acid and oxidizers such as concentrated nitric and chromic acid.

USES, APPLICATIONS

- Secondary containment areas/tank farms
- Concrete sumps, vaults and trenches
- Pump pads and pedestals
- Storage tanks
- Chemical storage rooms

PRODUCT ADVANTAGES

- Excellent chemical resistance to hydrofluoric acid
- Engineering fabric resists cracking
- Mortarcoat for added abrasion resistance
- Silica-free topcoat
- Factory proportioned units for easy application
- Non-sparking

CHEMICAL RESISTANCE

Stonchem 886 is formulated to resist a variety of chemical solutions. Refer to the Stonchem 800 Series Chemical Resistance Guide, which lists reagent concentration and temperature recommendations for each product.

PACKAGING

Stonchem 886 is packaged in units for easy handling. Each unit consists of:

Saturant

1.9 cartons of Stonchem 800/820 Liquids

Each carton contains:

- 2 jars of Peroxide
- 2 cans of Resin

Engineering Fabric

1 roll @ 18.58 m² roll

Mortarcoat

1.5 cartons of Stonchem 800/820 Liquids

Each carton contains:

- 2 jars of Peroxide
- 2 cans of Resin

3 bags of X20 Mortarcoat aggregate

Topcoat

1 carton of Stonchem 800 SF Topcoat

Each carton contains:

- 2 jars of Peroxide
- 2 cans of Resin

COVERAGE

Each unit of Stonchem 886 will cover approximately 16.72. m² at an application thickness of 1.5 mm. Note: If utilizing chopper gun applied fiberglass, there will be a reduction in saturant coverage. Questions regarding coverage rates should be directed to your local Stonhard representative or Technical Service.

STORAGE CONDITIONS

Store all components between 10 to 24°C in a dry area. Keep out of direct sunlight. Avoid excessive heat and do not freeze. The shelf life is 6 months in the original, unopened container. Store all engineering fabric in a clean and dry area.

PHYSICAL CHARACTERISTICS

Tensile Strength.	34 N/mm ²
(ASTM D-638)	
Flexural Strength	83 N/mm ²
(ASTM C-580)	
Flexural Modulus of Elasticity.....	4.1 x 10 ³ N/mm ²
(ASTM C-580)	
Hardness.	85 to 90
(ASTM D-2240, Shore D)	
Abrasion Resistance.....	0.10 gm max. weight loss
(ASTM D-4060, CS-17)	
Thermal Coefficient	
of Linear Expansion	3.6 x 10 ⁻⁵ m/mm°C
(ASTM C-531)	
Color	Gray
Cure Rate	4 to 6 hours tack-free
(@25°C).....	24 hours chemical service
VOC.....	800/820 liquids 53 g/l
(ASTM D-2369, Method E)	800 SF Topcoat 83 g/l

Note: The above physical properties were measured in accordance with the referenced standards. Samples of the actual floor system, including binder and filler, were used as test specimens. All sample preparation and testing is conducted in a laboratory environment, values obtained on field applied materials may vary and certain test methods can only be conducted on lab-made test coupons. Application and curing times are dependent upon ambient and surface conditions. Consult Stonhard's Technical Service Department if conditions are not within recommended guidelines.

SUBSTRATE

Stonchem 886 with appropriate primer, is suitable for application over concrete and the following uncoated newly-applied Stonhard mortars and grouts: GS, HT, UR, UT, TG6, TG8, CR5 and PM8. For questions regarding other possible substrates or an appropriate primer, contact your local Stonhard representative or Technical Service.

SUBSTRATE PREPARATION

Proper preparation is critical to ensure an adequate bond and system performance. The substrate must be dry and properly prepared utilizing mechanical methods. For existing coated surfaces, the coating must be completely removed back down to an intact mortar or substrate. Once the coating is removed, prime the prepared surface with Stonchem Epoxy Primer and broadcast with silica aggregate to refusal. Remove any excess silica aggregate prior to system overlayment. Omitting these steps could result in uncured material. Questions regarding substrate preparation should be directed to your local Stonhard representative or Technical Service.

APPLYING

Saturant - Basecoat

Mix peroxide and resin in a 20 liter bucket using a heavy-duty, slow-speed drill (400 to 600 rpm) with a mixing blade for one minute. Pour the saturant onto the substrate and spread out with a 15 mil notched squeegee. The saturant should be spread out in a sequence to allow application of the engineering fabric. Do not leave any puddling during this squeegee step. Puddling will lead to over saturation of the engineering fabric.

Engineering Fabric

Place the engineering fabric on the saturant immediately after the saturant is applied. This is important to achieve maximum wetting. Press the engineering fabric into the saturant with dry, medium nap roller. Overlap adjacent engineering fabric 26 mm. Immediately apply the saturant.

Saturant

Mix the peroxide and resin in a 20 liter mixing container using a heavy-duty, slow-speed drill (400 to 600 rpm) with a Jiffy Mixer for one minute. Apply the saturant to the engineering fabric with a saturated medium nap roller. To wet the roller, dip it into the mixing container. Always work from the mixing container. Do not pour the saturant directly onto the engineering fabric. This will decrease the saturant's coverage. If air temperature is high, the use of plastic buckets will increase the pot life of the material. The engineering fabric is completely saturated when white strands are no longer present. When the engineering fabric is completely saturated, roll with a ribbed roller to release air pockets in the reinforcement and to help mesh glass and saturant together. To saturate the overlaps, roll several times over the length of the overlap with a saturated roller. Then, roll with a ribbed roller several times until the overlap is no longer visible. Allow the saturant and engineering fabric to cure (usually 2 to 4 hours) before proceeding.

Mortarcoat

Lightly sand the engineering fabric/saturant in areas with protruding fibers. Pre-mix the peroxide and resin in a 20 liter mixing container using a heavy-duty, slow-speed drill (400 to 600 rpm) with a Jiffy Mixer for one minute. Next, gradually add the mortarcoat aggregate while mixing for an additional two minutes. For vertical applications, use vertical mortarcoat aggregate. Mixing is complete when no dry clumps of material exist. Pour the material onto the floor and spread out with a 4 mm notched squeegee. Backroll the area with a medium nap roller to remove squeegee lines. The material may appear rough at first but will level out to a smooth finish. For vertical surfaces, use a large steel trowel or knife to pull an initial coat of vertical material onto the wall, then finish smooth with a flat rubber squeegee.

Topcoat

Lightly sand the mortarcoat in areas where ridges or imperfections exist. Vacuum the area completely. Mix the peroxide and resin in a 20 liter mixing bucket using a heavy-duty, slow-speed drill (400 to 600 rpm) with a mixing blade for one minute. Pour the material onto the floor and spread out with a 4 mm notched squeegee. Backroll the area with a medium nap roller to remove squeegee lines, using long roll strokes to decrease the visibility of roller lines. For vertical surfaces, pour a bead of material along the base of the wall. Using a medium nap roller, roll the material up onto the wall. The wet film thickness of the coating is 250 to 300 microns. Check the thickness with a wet film gauge.

CURING

The surface of Stonchem 886 will be tack-free in one hour. Area may be returned to dry service after 4 hours and full service after 48 hours of cure at 21°C. Ultimate physical characteristics will be achieved in 7 days.

PRECAUTIONS

- Avoid contact with Stonchem 886 resin (vinyl ester resin and styrene monomer) and peroxide (catalyst/organic peroxide), as they may cause skin, respiratory and eye irritation.
- Acetone is recommended for cleanup of Stonchem 886 resin (vinyl ester resin and styrene monomer) and peroxide (catalyst/organic peroxide) material spills. Use these materials only in strict accordance with the manufacturer's recommended safety procedures. Dispose of waste materials in accordance with government regulations.
- The use of NIOSH approved respirators using an organic vapor/acid gas cartridge is mandatory.
- The selection of proper protective clothing and equipment will significantly reduce the risk of injury. Body covering apparel, safety goggles or safety glasses and impermeable gloves are required.
- In case of contact, flush area with water for 15 minutes and seek medical attention. Wash skin with soap and water.
- If material is ingested, immediately contact a physician. DO NOT INDUCE VOMITING.
- Use only with adequate ventilation. Inhalation of vapors may cause severe headaches, nausea and possibly unconsciousness.

NOTES


- Safety Data Sheets for Stonchem 886 are available online at www.stonhard.com under Products or upon request.
- Specific information regarding chemical resistance of Stonchem 886 is available in the Stonchem 800 Series Chemical Resistance Guide.
- A staff of technical service engineers is available to assist with installation or to answer questions related to Stonhard products.
- Requests for literature can be made through local sales representatives and offices or corporate offices located worldwide.
- The appearance of all floor, wall and lining systems will change over time due to normal wear, abrasion, traffic and cleaning. Generally, high-gloss coatings are subject to a reduction in gloss, while matte-finish coatings can increase in gloss level under normal operating conditions.
- Surface texture of resinous flooring surfaces can change over time as a result of wear and surface contaminants. Surfaces should be cleaned regularly and deep cleaned periodically to ensure no contaminant buildup occurs. Surfaces should be periodically inspected to ensure they are performing as expected and may require traction-enhancing maintenance to ensure they continue to meet expectations for the particular area and conditions of use.

CE MARKING

The harmonized European Standard EN 1504-2 „Products and systems for the protection and repair of concrete structures – Definitions, requirements, quality control and evaluation of conformity – Part 2 : Surface protection systems for concrete” gives specifications for products and systems based on methods “hydrophobic impregnation”, “impregnation” and “coating” for the various principles presented under EN 1504-9.

Products which fall under this specification have to be CE-labelled as per Annex ZA. 1, Tables ZA1a to ZA 1g according to the scope and relevant clauses there indicated and fulfill the requirements of the given mandate of the Construction Products Regulation nr. 305/2011.

For flooring systems not dedicated to protect or reinstate the integrity of a concrete structure, EN 13813 applies. Products acc. EN 1504-2 used as flooring systems with mechanical loads also must fulfil EN 13813. Here below indicated are the performance classes achieve according to the standard. For the specific performance results of the product to the particular tests, please see the actual values above in the PDS.


Stoncor Europe Rue du Travail 9 1400 Nivelles, Belgium 22
DOP.886.2022.23.03 EN 1504-2
Surface Protection Product Ingress Protection 1.3 (C) Physical Resistance 5.1 (C)
Cap. Absorption & Permeability to Water Vapor..... $W < 0.1 \text{ kg/m}^2 \cdot \text{h}^{0.5}$ Water PermeabilityClass III Permeability to CO ₂ $S_d > 50\text{m}$ Adhesion Strength by Pull-Off Test $> 2.0 \text{ MPa}$ Fire Resistance B_{fl-s1} Abrasion Resistance..... $< 3000\text{mg}$, H-22 Impact ResistanceClass III

IMPORTANT:

Stonhard believes the information contained here to be true and accurate as of the date of publication. Stonhard makes no warranty, expressed or implied, based on this literature and assumes no responsibility for consequential or incidental damages in the use of the systems described, including any warranty of merchantability or fitness. Information contained here is for evaluation only. We further reserve the right to modify and change products or literature at any time and without prior notice.

Rev.03/22
 © 2022 Stonhard www.stonhard.com



European Offices:

Belgium	+32 674 93 710	Spain	+34 933 623 785	Germany	+49 240 541 740
France	+33 160 064 419	Portugal	+351 227 535 642	The Netherlands	+31 165 585 200
Poland	+48 422 112 768	United Kindom	+44 1925 649 458	Italy	+39 022 53 751
		East Europe	+48 422 112 768		